

Windows Driver Manual

Rev. 1.0

POS Printer

CONTENTS

1. Manual Information	1
2. Operating System(OS) Environment	1
3. Windows Driver Preparation	1
4. Windows Driver Installation	2
5. Detailed Windows Driver Setting	7
5.1 Printing Preferences	7
5.2 Other Settings	23
6. Uninstall Windows Driver	25
7. Specification	27

1. Manual Information

This Windows Driver Installation Manual provides information on installation, detailed specifications, and usage of the printer's Windows Driver according to PC operating system (OS).

We maintain ongoing efforts to enhance and upgrade the functions and quality of all our products. As follows, product specifications and/or user manual content may be changed without prior notice.

2. Operating System(OS) Environment

The following operating systems are supported for usage.

- Microsoft Windows 10 (32 bit/64 bit)
- Microsoft Windows 8 (32 bit/64 bit)
- Microsoft Windows 7 SPI (32 bit/64 bit)
- Microsoft Windows Vista SP2 (32 bit/64 bit)
- Microsoft Windows XP Professional SP3 (32 bit)
- Microsoft Windows Server 2012(64 bit)
- Microsoft Windows Server 2008 R2
- Microsoft Windows Server 2008 SP2(32 bit/64 bit)
- Microsoft Windows Server 2003 R2 SP2(32 bit/64 bit)

3. Windows Driver Preparation

The Windows Driver is included in the enclosed CD.

The installation file name is POS Printer Driver-v-X.X.X.X.exe

eg : POS Printer Driver-v-2.5.5.0.exe


4. Windows Driver Installation




Warning:

Under different operating system, the screen has slight difference. Please operate it according to the tips. Take POS80FE (Windows 7) as example.


- (1) Double click Windows Driver.
- (2) Choose "I accept the agreement" and click "Next".



(3) Click “Next”



- (4) Choose the matched type and port (USBxxx is for USB port, COMx is for serial port, LPTx is for parallel port). Choose the type and port of driver, such as “POS80FE”, “COM1” . Click “Next”.



NOTE: If printer is already connected with computer by USB port, it only needs to click “Install”, then it will be installed automatically. Otherwise, proceed to the next step.

(5) Click "Finish". POS printer driver is installed successfully.



(6) After installation, the icon will be found in "Start"→"Devices and Printers".




NOTE: If you already installed the driver (No matter what kind of port), when you connect the printer with computer, it will create a USB port automatically.


5. Detailed Windows Driver Setting

5.1 Printing Preferences


- 1) Click "Start"→"Devices and Printers". Right click "POS80FE" and choose "Printing preferences".




2) According to the different needs, choose “Paper”\“Offset”\“Rotate”\“Effect”\“Copies” in “Paper”.




- Click on “Manager”, add or delete paper.




- Click on “Advanced” to set “Save Paper”、“Cut Paper”、“Feed Paper”、“Cash Drawer”、“Custom Command”、“Logo”、“Buzzer”、“Code Page”.



3) Click “Watermark”. Set watermark to print.




- 4) Click “Halftone” to set the halftone.



5) Click “Printer Setting” to set “Language For Properties Display” and “Font Substitution”.


- Choose the “Display Language for Properties”.




- Turn on the “Font Substitution”.






- Select the “System Font”, for example: Arial.



- Select the font to that you went to replace.



- Click “Setting”.





6) Set up the “Barcode”

Assuming the font type of the main document is “Italics”, if you want to convert the data “123456” to the barcode printing, the steps are as follows:



- Sets the data "123456" font type to a different font from the main document.

Such as: Arial.




- Open the Preference.


If the document is open, you can set it in the document: file-print-preferences.






- Click the “Printer Setting”.
- Turn on the “Font Substitution”, select the system text need to be replaced (for example, Arial), and then select the font you want to replace (for example, 01) and click Settings, and the replacement font will display "01".

the steps are as follows:











7) After all the setting, click “OK” to save it.

5.2 Other Settings

- (1) Click "Start" → "Devices and Printers". Right click "POS80FE" and choose "Printer properties".




- (2) Choose “General”, click on “Print Test Page”, then it will print the current settings.




6. Uninstall Windows Driver

- 1) Double click Windows Driver.
- 2) Choose “Uninstall printer driver”, then click “Next”



3) Choose “POS80FE”, then click “Next”



4) Then it is complete to uninstall.

7. Specification

Resolution:

POS80FE: 203×203dpi

Paper Size:

Custom(72.0mm * 297.0mm)